

CDI 5200-DG

Drill Guide Instructions

Caution:

- *Make sure the air pressure is bled down completely before drilling the holes.*
- *Wear safety glasses.*
- *Clamp the drill guide firmly in place.*

Drilling the holes to install the meter will release some metal shavings into the pipe. When planning the installation, make sure that all downstream equipment is protected by filters, or take other precautions to ensure that shavings do not reach critical equipment or get blown out in a way that could cause injury.

Shut off the supply of air to the pipe where the meter will be mounted and allow the pressure to bleed down. Clamp the drill guide firmly to the pipe, orienting it for visibility of the meter. A chain clamp, a C clamp or a band clamp may be used. The backing piece provided will help to support a C clamp on small pipe. Drill the two holes and remove any resulting burrs from the outside surface of the pipe. Make sure the outside surface of the pipe is clean and smooth before installing the flowmeter.

CDI Meters, Inc
www.cdimeters.com

866-885-2462

06/10/09

© CDI Meters, Inc. 2009