

CDIMS USB Drivers

When the meter is connected to the PC for the first time the PC will look for a USBdriver (a small program that allows the PC to communicate on that connection).

If the PC is connected to the internet this process is automatic, but it may take a few minutes.

If difficulties are encountered follow the advice in the FTDI Driver Installation Guides for Windows 7, 8 and 10:

https://www.ftdichip.com/Support/Documents/AppNotes/AN_119_FTDI_Drivers_Installation_Guide_for_Windows7.pdf

https://www.ftdichip.com/Support/Documents/AppNotes/AN_234_FTDI_Drivers_Installation_Guide_for_Windows_8.pdf

https://www.ftdichip.com/Support/Documents/InstallGuides/AN_396%20FTDI%20Drivers%20Installation%20Guide%20for%20Windows%2010.pdf